



SP1100WinoX-M

Spare parts list for SP1100DWINOX-M			
Pos no	Reference no	English description	QTY
1	DJ.DL.001	cable and plug	1
2	DJ.KG.00407	switch	1
3	XJ.FT.007	cable pressing sleeve	1
4	ZS.5II10/ZS.5II11	handle	1
5	WJ.LD.004 X 1253	screw ST4.2*12.5	6
6	WJ.XG.001	thread clamp	1
7	WJ.BK.007	main pump	1
8	WJ.LD.004*125	screw ST4.2*12.5	6
9	XJ.OX.011*31	O-ring Φ 11.8*3	2
10	ZS.2.20	pump case	1
11	WJ.DJHG.001	Motor iron rear cover	1
12	WJ.LD.004*27	screw ST3.9*27.5	3
13	ZS.7.4	capacitance briquetting 2#	1
14	DJ.DR.012	capacitance 12uf	1
15	ZS.7.1/ZS.7.2	cable button up	2
16	XJ.FT.021/XJ.FT.051	cable sheath	2
17	XJ.QT.087	air outlet	1
18	WJ.GQ.001	steel ball SØ6	1
19	WJ.LM.004	gasket	1
20	WJ.ZC.002	bearing 6201	1
21	DJ.ZZ.024YTS	rotor 15#	1
22	DJ.DZ.005	stator Φ 90*55B	1
23	WJ.QG.014		1
24	WJ.JJ.002	reinforced seal 12*24*4.5	1
25	WJ.JJ.003	mechanical seal	1
26	WJ.KH.001	jump ring	1
27	WJ.DP.00701	regulator gasket Φ 8*14*0.5	3
28	ZS.YL.PAB586-34	impeller	1
29	WJ.LM.003	locknut	1
30	XJ.OX.089*511	O-ring 89*5.1	1
31	ZS.2.11		1
32	WJ.LD.004 X 40	screw ST4.2*40	6
33	ZS.2.28		1
34	XJ.PD.0111		1
35	ZSZ.5.II12	base	1
36	ZS.7.47	output	1
37	XJ.OX.037*31	O-ring 37.5*3	2
38	ZS.7.41	elbow	1
39	ZS.1.40	plate	1
40	WJ.LD.004*13	screw ST4.2*40	3+1