



Spare parts for REV3816			
Pos Nr	Reference Nr	English Description	QTY
1	WR6006-1600-300-21	200 wheel cover	2
2	GB845-85	Φ8*Φ16*1.5 gasket	2
3	WR6006-1600-700-13	pressplate	2
4	WR6006-1600-400-08	front wheel spindle Assembly	1
5	WR6006-1600-300-20	200 wheel	2
6	WR6006-1600-300-05	Front decorative panel	1
7	WR6006-1600-700-08	Filter sponge NO.2	1
8	WR6006-1600-700-07	Filter sponge NO.1	1
9	WR6006-1600-700-09	Filter sponge NO.3	1
10	GB845-85	NUT 12*12*6 M8	1
11	WR8001-1400-300-24	pressplate	1
12	WR6006-1600-300-13	breakwind	1
13	WR6006-1600-300-02	Housing cover	1
14	WR6006-1600-300-04	housing handle	1
15	WR6006-1600-300-17	grass bag fixing pin	1
16	WR6006-1600-400-04	spring	1
17	WR6006-1600-300-03	grass bag cover	1
18	WR6006-1600-300-16	Torsion spring fixing pin	1
19	WR6007-1840-500-02	protector 17AMG/95G+PTC	1
20	WR6006-1600-300-22	sandbag	1
21	WR6006-1600-300-01	Base	1
22	WR6006-1600-400-03	back wheel spindle	2
23	GB845-85	screw ST5*25	2
24	WR6002-1500-300-03	150 wheel	2
25	GB845-85	Φ10*Φ20*1.5 gasket	2
26	WR8018-1500-300-12	150 wheel cover	2
27	GB845-85	NUT M6*5	1
28	GB845-85	NUT M5	1
29	WR6006-1600-300-08	bearing block	1
30	GB845-85	NUT M5*25	1
31	GB845-85	Inner hexagon spanner	1
32	GB845-85	Φ6*Φ12*1 gasket	1
33	WR6006-1600-300-09	press plate	1
34	GB845-85	nut M6*30	1
35	WR6006-1600-300-07	depth adjust handle (right)	1
36	WR6006-1600-300-06	depth adjust handle (left )	1
37	GB845-85	screw ST4*16	2
38	GB845-85	R pinΦ2*20mm	4
39	WR6006-1600-700-06	grass collect frame	1
40	WR6006-1600-700-10	grass collect bag	1
41	GB845-85	screw ST4*18	21
42	GB845-85	screw ST5*25	3
43	WR8001-1400-300-35	knob	4
44	GB845-85	nut Φ10*19---M6*0.75	4
45	WR8001-1400-300-36	Gasket	4

46	WR6006-1600-700-04	No.2 rod	1
47	GB845-85	screw M6*52	4
48	WR8001-1400-300-23	cable strain relief	1
49	WR6006-1600-300-19	cable clamp	1
50	WR6006-1600-300-11	no.1 rod seat	2
51	WR6006-1600-700-03	no. 1 rod	2
52	GB845-85	screw ST4*12	4
53	WR6006-1600-300-12	knob	2
54	GB845-85	screw M8*50	2
100		motor assembly	1
101	GB845-85	ring Φ8	1
102	WR6001-1500-300-14	motor fan	1
103	GB845-85	screw ST3*12	2
104	WR8001-1400-600-01	carbon brush	2
105	WR8001-1400-600-02	carbon brush holder	2
106	WR6001-1500-300-13	housing	1
107	WR6006-1600-200	stator assembly	1
107-1	WR6006-1600-500-01	inductance	2
108	GB845-85	screw ST4*65	2
109	GB845-85	gasketΦ21*Φ16.5*2	1
110	GB/T276-1994	bearing 608-2RS	1
111	WR6006-1600-100	Rotor assembly	1
112	GB/T276-1994	bearing 6900-2RS	2
113	WR6001-1500-700-13-01	gasketΦ10.1*22*0.5	2
114	WR6001-1500-700-12	wool felt Φ8*Φ16*1.5	1
115	WR6001-1500-400-09	gear box	1
116	GB/T276-1994	bearing HK0608	1
117	GB845-85	ring Φ10	1
118	WR6001-1500-400-07	wheel	1
119	GB/T276-1994	bering ZZ-608	1
120	WR6006-1600-300-14	centre frame	1
121	GB845-85	screw ST4*20	3
122	GB845-85	screw M4*20	3
123	WR6006-1600-400-06	output axis	1
124		belt	1
125	WR6006-1600-300-15	centre frame cover	1
126	GB845-85	nut	1
127	GB/T276-1994	bearing6000-2RS	1
128	WR6001-1500-400-18	wheel	1
129	GB/T276-1994	bearing6002-2RS	1
130	GB845-85	gasket	1
131		axis	1
132	WR6006-1600-400-07	axis	1
133	GB845-85	screw ST4*20	3
41	GB845-85	screw ST4*18	5
42	GB845-85	screw ST5*25	2

200		Switch assembly	1
201	WR6007-1840-300-18	Trigger seat left	1
202	WR6007-1840-400-09	spring	1
203	WR6007-1840-300-20	wire connected rod	1
204	WR6007-1840-300-19	trigger seat right	1
205	GB845-85	screw ST4*25	2
206	WR6007-1840-300-15	switch box pressplate	1
207	WR6007-1840-300-13	switch box left	1
208	WR6007-1840-500-01	wire	1
209	WR8001-1400-500-05H	pulg	1
210	WR8001-1400-300-25	cable sleeve	1
211	WR6007-1840-700-10	Switch reset shrapnel	2
212		Rocker switch	1
213	WR8001-1400-400-29	spring	1
214	WR6007-1840-300-16	trigger	1
215	WR8001-1400-500-06	capacitance	1
216	WR6007-1840-300-17	switch button	1
217	WR6007-1840-300-14	switch box	1
218	WR6006-1600-700-05	no. 3 rod	1
219		sponge tube	1
220	WR6007-1840-700-14	Wire trigger	1
133	GB845-85	screw ST4*20	3
11	WR8001-1400-300-24	cable pressplate	2
37	GB845-85	screwST4*16	2
41	GB845-85	screwST4*18	8
300		Aerator assembly ( 8 blade)	1
301	WR6001-1500-400-05	Connecting axle	1
302	GB845-85	Washer for axle	1
303	WR6006-1600-400-02	iron bushing for blade	1
304	GB845-85	Elastic cylindrical pin	1
305	WR6006-1600-700-01	128Blade	8
306	WR6006-1600-300-23	Plastic bushing	7
307	WR6006-1600-400-01	iron bushing for blade	1
308	WR6001-1500-400-18-01	Dustproof cover plate left	1
309	WR6001-1500-700-05	Washer	1
310	WR6006-1600-700-12	axle	1
117	GB845-85	Retaining ring	1
127	GB/T276-1994	Bearing	1
400		Scarifier Assembly	1
401	WR6001-1500-300-16	Cover plate	13
402	WR6001-1500-300-17	Fixed frame	12
403	WR6001-1500-400-04	Claw spring	24
404	WR6006-1600-700-11	axle	1
117	GB845-85	Retaining ring	1
127	GB/T276-1994	Bearing	1
301	WR6001-1500-400-05	Connecting axle	1
302	GB845-85	Washer for axle	1
308	WR6001-1500-400-18-01	Dustproof cover plate left	1